

# Idle Relearn Procedure

For Honda K-Series Motors

## OVERVIEW

For the ECM/PCM to learn the engine idle characteristics, this procedure must be done.

## PROCEDURE

1. Ensure all electrical items (A/C, audio, rear window defogger, lights, etc.,) are off.
2. Start the engine, and hold it at 3,000 rpm with no load (transmission in park or neutral) until the radiator fan comes on, or until the engine coolant temperature reaches 90°C (194°F).
3. Let the engine idle for a minimum of 5 minutes with no load.

## NOTE:

If the radiator fan cycles during this time, do not include its running time in the 5 minutes.